

# Formotion INSTRUCTIONS

REV. 2007-05-23

## Stem Nut Covers

### PARTS LIST

Qty.	Item
1	Stem nut cover
1	Insert clock
1	Small Hex Key (for use w/ 28-38mm covers only)
1	Countersunk socket head screw (for use w/ 39-57mm covers only)

### INSTALLATION

1. Set time on clock: To access the crown, remove rubber gasket. Pull out the crown and turn to set the time. Push crown back in and replace gasket to original position. The inner ridge of the gasket should fit into the groove on the clock.
2. For 28-38mm Stem Nut Covers: Install the stem nut cover over the stem nut. Rotate the cover so that the set screw is perpendicular to the flat side of the stem nut.
3. Snug the pre-installed set screw using small hex key provided. **DO NOT OVERTIGHTEN!!!**
4. Press Clock into Stem Nut Cover. If clock doesn't fit into the Stem Nut Cover, see step 1 - you may have installed the rubber gasket incorrectly.
5. For 39-57mm Stem Nut Covers: Remove existing stem nut cover (if applicable)
6. Place Stem Nut Cover over stem nut. Snug the countersunk socket head screw using hex key provided. **DO NOT OVERTIGHTEN!!!**
7. Press Clock into Stem Nut Cover. If clock doesn't fit into the Stem Nut Cover, see step 1 - you may have installed the rubber gasket incorrectly.

To activate your limited lifetime warranty and 1 year manufacturer defect warranty (see our website for details) please register your purchase at: [www.FormotionProducts.com](http://www.FormotionProducts.com) or Call Formotion Product Registration at 1-888-747-2218. You can also Fax or Mail the following information to us at:

Formotion Inc.  
Product Registration  
30 Liberty Ship Way STE 3110  
Sausalito, CA 94965

FAX: 415-331-0440

Name \_\_\_\_\_  
Address \_\_\_\_\_  
City \_\_\_\_\_ State \_\_\_\_\_  
Zip \_\_\_\_\_  
E-Mail \_\_\_\_\_  
Model(s) \_\_\_\_\_